

# Development of the Rotary Microfilter for Treating Radioactive Liquid Waste



**We Put Science To Work**

**Michael Poirier, David Herman , and Samuel Fink  
Savannah River National Laboratory  
Savannah River/Hanford/Idaho Technical Exchange  
October 9, 2007  
WSRC-STI-2007-00527**

# Introduction

- **An alternative process to treat radioactive liquid waste at SRS is ion exchange**
- **First step is MST addition to sorb strontium and select actinides**
  - **Followed by filtration to remove MST and entrained sludge**
- **Filtrate processed through ion exchange (or solvent extraction) process to remove cesium**
- **Crossflow filter testing showed filtration rates less than desired**
- **Baseline design had 3000 ft<sup>2</sup> crossflow filter and 5000 gpm filter feed pump**
  - **large filter and pump needed will significantly increase footprint**
- **Investigated methods to improve separation of sludge and MST solids from high level waste salt solution**

# Alternative Technologies Investigated


- **Alternate crossflow filters**
  - Smaller pore size Mott filters
  - Graver filter
  - ***Rotary Microfilter***
  - Vibratory Shear Enhanced Processing (VSEP) Filter
  - Vacco filter
- **Dead-end filtration**
- **Settling and decanting**
  - No polishing step
  - Dead-end filtration polishing step
  - Crossflow filtration polishing step
- **Centrifuge**
- **Magnetic filter**

# Scoping Rotary Filter Test

- **Objective**
  - Perform test with SRS HLW simulant to evaluate rotary microfilter
- **Test performed with SpinTek Rotary Microfilter**
- **5.6 M Na average salt solution simulant**
- **0.06 - 6.0 wt % insoluble solids (Tank 40H simulated sludge and MST)**
- **Measured filter flux as a function of operating parameters**
- **Measured filtrate turbidity**

# SpinTek Rotary Microfilter

- 1 - 25 filter disks
- 11 inch diameter
- 1170 rpm
- 60 ft/s tip speed
- 40 psi TMP
- Filter disks
  - 0.1  $\mu$  ceramic membrane/SS backing
  - Polyethylene mesh
  - Ryton™ support structure
- Turbulence promoters/baffles above and below disks increase shear and reduce cake buildup



# SpinTek versus Mott

<u>Solids (g/L)</u>	<u>Speed (rpm)</u>	<u>Flux (gpm/ft<sup>2</sup>)</u>	
		<u>Rotary (measured)</u>	<u>Cross-Flow (predicted)</u>
0.6	1170	0.21	0.08
2.8	1170	0.19	0.07
12.9	1170	0.15	0.04
60.0	1170	0.13	0.02
60.0	148	0.04	0.02

Rotary filter operating at 40 psi.

Rotary filter used 0.1  $\mu$  ceramic filter

Crossflow filter used 0.5  $\mu$  SS

Cross-flow operating at 40 psi and 10 ft/s - predicted from pilot-scale data.

# Path Forward

---


- **Procure 0.05 gpm unit for actual waste test**
- **Procure 0.5 gpm unit for pilot-scale testing**

# SpinTek Filter for Actual Waste Testing




- **Equilibrated feed solution**
  - SRS supernate
  - SRS sludge
- **Added 0.55 g/L MST - mixed for 24 hrs**
- **Operated filter at**
  - 30, 40, 50 psig TMP and
  - 1170 rpm filter speed
- **Collected filtrate samples**
- **Measured filter flux**
- **Added additional sludge and MST**
- **Performed additional filter tests**

# Actual Waste MST Data - 4.5 wt%



6 - 10X increase in filter flux at 4.5 wt % solids loading with 0.5  $\mu$  SpinTek

# SpinTek Actual Waste Test




# Pilot Testing

- **3 disk filter unit**
- **0.1  $\mu$  filter sintered stainless steel membrane**
- **Prepared feed solution at lowest solids concentration (0.09 wt %)**
- **Operated filter for 125 hours varying TMP periodically**
- **Measured filter flux and filtrate turbidity**
- **Added additional solids and ran for additional 125 hours (0.29 wt %)**
- **Added additional solids and ran for additional 125 hours (1.29 wt %)**
- **Added additional solids and ran for additional 125 hours (4.5 wt %)**
- **Conducted 2 hour rotor stop test**


# Pilot-Scale Rotary Filter Unit



# Pilot-Scale Data (MST)



# Pilot-Scale Data (MST)



# Operability

- **Performed tests at nominal solids concentrations of 0.06, 0.28, 1.29, and 4.5 wt %**
- **Completed 500-hour test with no problems**
- **Stopped the rotor for two hours and restarted it without incident.**
- **After filter cleaning, inspection of the disk revealed only a small amount of particles on surface of the filter near center of disk**


# Filter Disk Following 500 Hour Test



# Filter Media Selection

- **2003 USC Pilot Testing**
  - Irradiated disks
  - 0.5 micron Mott SS
  - 0.1 micron Mott SS
  - 0.1 micron TruMem® ceramic
  - Ceramic produced highest flux
- **Alternative Crossflow Filter Media Evaluation**
  - Compared Mott, Graver, GKN, and Pall media
  - Pall and Graver media produced highest flux
  - Graver media not available in flat sheets
- **2004 USC Pilot Testing**
  - Welded disks
  - 0.1 micron Mott SS
  - 0.1 micron TruMem® ceramic
  - 0.1 micron Pall SS
  - Ceramic produced highest flux
  - Pall media produced higher flux than Mott media
- **2005 SRNL Tests**
  - Scoping Tests (Stirred Cell)
  - Rotary Filter Tests

# Comparison of Media in 3-Disk Rotary Filter



0.1  $\mu$  TruMem and 0.5  $\mu$  Pall produce highest flux


# Recommendation

- **Recommend Pall PMM M050 filter media for rotary microfilter (0.5  $\mu$  nominal)**
  - Highest flux of SS media tested
  - Met turbidity criteria
  - Demonstrated fabrication with three disks
  - More durable than TruMem media

# Filter Modifications for Radioactive Service

- **Removable disk stack**
- **Stainless steel support plate**
- **Stainless steel rather than ceramic membranes**
- **Stainless steel mesh**
- **Welding membranes to support plate**
- **Alternative mechanical seal**
- **Patented design improvements and licensed technology**
- **Funded by EM-21**

# Deployment Design – Pump/Filter Module



- SRNL, ORNL, TTI, and SRS LWO developed design to place 2 rotary filters in tank riser as prefilter to ion exchange process
- Pump/Filter module at 100% design for SRS Waste Tank Type B riser

# Full-Scale Rotary Filter at SRNL

Motor

25 disk filter unit




**Manufacturer  
Recommends  
25 – 50 gpm  
pump – *much  
smaller than  
pump  
requirements for  
crossflow filter***

# Small Column Ion Exchange (SCIX) Prefilter Test

- Reused 5.6 M sodium salt from previous filter test
- Added Sludge Batch 2 sludge (target 0.06 – 4.5 wt % solids)
- Feed pressure 40 – 95 psi
- TMP 40 psi
- Temperature 30 – 40 °C
- Feed flow rate ~ 25 gpm


# SCIX Prefilter Test Data



Flux significantly above crossflow filter

Flux > 0.2 gpm/ft<sup>2</sup> (10 gpm) with simulated SCIX feed (0.06 wt % solids)

# Filter Feed and Filtrate




No visible solids in filtrate

# Sludge Washing

**Objective: Remove the soluble solids (Na) from sludge to prepare for processing in the Defense Waste Processing Facility**

- **Placed 80 gallons of simulated sludge (with 3 M sodium supernate) in filter feed tank**
- **Operated filter at ~ 18 gpm feed rate, 40 psi TMP, 27-33 °C**
- **Filtrate removed from system**
- **Added inhibited water (0.01 M NaOH, 0.011 M NaNO<sub>3</sub>) to feed tank at same rate filtrate was withdrawn**
- **Filtrate samples collected and analyzed for sodium and density**
- **Filtrate rate measured**
- **Following washing, recirculated filtrate for 2 hours**
- **Concentrated solids to ~ 20 wt % and recirculated for 2 hours**


# Filtration Rate During Sludge Washing



**Filtrate rate decreased slightly as solids loading increased from 4.5 wt % to 15 wt % (flow rates corrected to 35 °C)**

Development of the Rotary Microfilter for Treating Radioactive Liquid Waste


# Sodium Concentration During Washing



**Filter system behaves as Continuous Stirred Tank Reactor (CSTR)**

Development of the Rotary Microfilter for Treating Radioactive Liquid Waste

# Filtrate Turbidity




**All samples < 5 NTU**

# Video of Filter Stack Removal after Rinsing



**Video of removal of  
filter stack after  
rinsing**

# Filter Stack after Rinsing with Water



**Bulk of slurry rinsed from filter stack. Filter cake still evident on disks.  
684 g of sludge (dried weight) on filter disks.**

# Conclusions

- Rotary filter flux 2.5 – 6.5X higher in vendor scoping tests
- Rotary filter flux 6 – 10X higher in actual waste tests
- Rotary filter flux ~ 2X higher in pilot-scale tests
- Pilot-scale unit ran over 4000 hours with no significant operating problems
- Rotary filter upgraded for radioactive service
- Design developed to place two filters in SRS Tank riser
- Rotary filter flux ~ 6X higher in full scale tests

# Path Forward

- **Replace SiC rotary seal with air seal**
- **Upgrade bushing**
- **Perform Tests for Hanford Supplemental Pretreatment**
  - Tank AN-105
  - Oct – Dec 2007
- **Perform Tests for SRS Modular Salt Processing**
  - Dec 2007 – Feb 2008
- **Perform Tests for SRS Sludge Washing**
  - Jan 2007 – Feb 2008
- **Obtain additional operating time**
- **EM-20 Funded**

# Acknowledgements

---

- **DOE EM-21 (Chet Miller, Pat Suggs)**
- **SpinTek**
- **Larry Parker**
- **David Maxwell**
- **Rick Minichan**
- **Sammie McDuffie and Henry Bolton**

# Q & A

---

# Contact Information

---

**Michael Poirier**

**Fellow Engineer**

**Savannah River National Laboratory**

**773-42A**

**Aiken, SC 29808**

**803-725-1611**

**[michael.poirier@srnl.doe.gov](mailto:michael.poirier@srnl.doe.gov)**